

User Manual for Artfone CS182 Senior Phone



Specifications

- Network: GSM 2G (dual SIM)
- Size: 118 x 55 x 14.5mm
- Weight: 90,7g
- Display size: 1.77" TFT, 120x160 pixels
- Battery capacity: 1400mAh
- Memory: 32MB
- Bluetooth 2.1
- FM radio
- Camera 0.08 MP
- Max. microSD card size: 16GB



- | | |
|----------------------------|-----------------------------------|
| 1. Speaker | 9. 0 button/Switching the profile |
| 2. LCD display | 10. 3.5mm audio jack |
| 3. Left soft key | 11. MicroUSB port |
| 4. Right soft key | 12. LED flashlight |
| 5. Up/Down buttons | 13. Lock keypad |
| 6. Answer/Take a call | 14. Unlock keypad |
| 7. End a call/Power On/Off | 15. Flashlight On/Off button |
| 8. Numeric pad | |

Icon description



Shows actual GSM signal



Unread message



Shows normal profile



Headphones plugged-in



Alarm is set up



Enabled Bluetooth



Battery status

How to power on?

Press the red button for 2.5 seconds.


How to power off?

Make sure the keypad is unlocked, then press the red button for 2.5 seconds.

How to use a flashlight?

Just press the No.15 button on the side to turn on or turn off the flashlight.

How to use the SOS function?



- Status: Set the function on or off here:
- SOS numbers: This is very important, you can set no more than 5 telephone numbers here. When you press the SOS button, the phone will dial the numbers one by one automatically.
- SOS SMS: You can edit SMS
- SOS SMS ON/OFF: You can turn on or off SOS message

How to make a call?

1. Speed dial: long-press numbers 1-9
2. Input a telephone number and press the left green button
3. Find a contact in the phonebook and press the left green button
4. SOS special dial: press the SOS button and the phone will dial pre-set SOS number automatically

Volume adjustment

Press the side button + or - to adjust the volume.

How to change ringtone/message tone/volume?

Go to Settings → Profiles → General → Customize

Restore to factory settings:

Settings → Phone settings → Restore factory settings → Password is 1234

How to use a camera?

1. Press the Down button and open the camera.
2. Take photos by pressing the “1” button on the Numeric pad.

FAQ

1. SIM card: The phone supports nano and micro SIM, but it is best to use a standard SIM card.



2. Does this phone work on a 3G network?
 - No, it is a 2G GSM phone, that supports quad bands: 850/900/1800/1900.
3. Can the Artfone CS182 connect to the internet and does it support MMS?
 - No, it can't connect to the internet and doesn't support MMS.
4. Is the phone unlocked?

Yes, all Artfone phones are unlocked and work well on 2G GSM networks around the world.
5. Does the phone packaging include earphones?

No, but it has a 3.5mm port, compatible with most earphones on the market.